



G:\My Drive\Epro Master Folder\Drafting\Details\Transitions\E.Protect\2.140.2.1 UNDERSLAB ASSEMBLY - TRANSITION TO SHORING ASSEMBLY - SHOTCRETE.dwg [Detail] September 27, 2021 - 9:37am

UNDERSLAB ASSEMBLY - TRANSITION TO SHORING ASSEMBLY - SHOTCRETE

	SYSTEM NAME	DRAWING NUMBER	
	E.PROTECT	2.140.2.1	
	DRAFTER	DATE	
	RJT	9/27/2021	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1