



G:\My Drive\epro Master Folder\Drafting\Details\Overexcavated Walls\E.Protect\2.247.1.WALL ASSEMBLY TRANSITION TO SELF ADHERED MEMBRANE.dwg [Detail] March 19, 2019 11:08am

WALL ASSEMBLY TERMINATION TRANSITION TO SELF ADHERED MEMBRANE

	SYSTEM NAME	DRAWING NUMBER	
	E.PROTECT	2.247.1	
	DRAFTER	DATE	
	TSH	03/19/19	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1