



G:\My Drive\epro Master Folder\Drafting\Details\Transitions\E.Protect+3.140.2 UNDERSLAB ASSEMBLY TRANSITION TO SHOTCRETE SHORING ASSEMBLY.dwg [Detail] March 10, 2020 - 11:07am

UNDERSLAB ASSEMBLY TRANSITION TO SHOTCRETE SHORING ASSEMBLY

	SYSTEM NAME	DRAWING NUMBER	
	E.PROTECT+	3.140.2	
	DRAFTER	DATE	
	RJT	3/10/2020	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1