



NOTES:

- 1) NOVATAK MEMBRANE BOOT MUST BE FIT SNUG AROUND CONDUIT/PIPE WITHOUT FOLDING OF FALLING DOWN. NOVATAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PILE, TIGHTEN HOSE CLAMP AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE
- 2) SPACE PENETRATIONS A MINIMUM OF 6" FROM SLAB EDGE, CORNERS, WALLS, OR OTHER PENETRATIONS.

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Novatak\50.320.1 VERTICAL PIPE PENETRATION - FIELD MANUFACTURED PIPE COLLAR.dwg [Detail] June 01, 2020 - 10:54am

VERTICAL PIPE PENETRATION - FIELD MANUFACTURED PIPE COLLAR

	SYSTEM NAME	DRAWING NUMBER	
	NOVATAK	50.320.1	
	DRAFTER	DATE	
	RJT	5/26/2020	

AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1