



- NELSON STUD (LAGGING SIDE):**
- 1) SLIDE ON A 2" DIAMETER X 1/8" THICK S.S. WASHER AGAINST STEEL BEAM
 - 2) SLIDE ON A 2" DIAMETER X 1/8" THICK RUBBER WASHER
 - 3) CUT A MAX. 1/2" HOLE IN NOVATAK MEMBRANE AND SLIDE ON TO NELSON STUD AGAINST RUBBER WASHER

- NELSON STUD (NOVATAK SIDE):**
- 4) APPLY BEAD OF E.STOP GU AROUND BASE OF NELSON STUD
 - 5) SLIDE ON A 2" DIAMETER X 1/8" THICK RUBBER WASHER AGAINST NOVATAK
 - 6) SLIDE ON A 2" DIAMETER X 1/8" THICK S.S. WASHER
 - 7) INSTALL THREADED 1/2" FASTENER/NUT AND TIGHTEN AGAINST NOVATAK SHEET

- NELSON STUD (CONCRETE POUR SIDE):**
- 8) SEAL WITH NOVASEAL 5000

1/2" FULLY THREADED NELSON STUD WELDED TO STEEL I-BEAM

NOVATAK, w/WHITE RELEASE SHEET FACING INSTALLER

I-BEAM OR SOLDIER PILES WOOD LAGGING / SOE

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Novatak\50.326.3 BLINDSIDE VERTICAL PENETRATION - NELSON STUD.dwg [Detail] July 01, 2021 - 9:53am

BLINDSIDE VERTICAL PENETRATION - NELSON STUD

	SYSTEM NAME	DRAWING NUMBER	<h1>NOVATAK</h1>
	NOVATAK	50.326.3	
	DRAFTER	DATE	
	RJT	6/21/2021	

AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.