

PRETAK COLLAR WRAP AND TARGET PATCH



w/ PSA TOWARDS CONCRETE

- 1) OVERLAP COLLAR MIN. 4" WITH 6" WIDE PRETAK COLLAR WRAP
- 2) FOLD PRETAK COLLAR IN HALF LENGTHWISE AND CUT 1" WIDE FLAPS TO CENTER LINE
- 3) ADHERE COLLAR TIGHTLY TO PRETAP D ON PENETRATION WITH FLAPS ON SUBSTRATE
- 4) APPLY PRETAP E OVER FLAPS
- 5) SLIDE STAR CUT TARGET PATCH TIGHTLY OVER PENETRATION AND ADHERE TO FLAPS
- 6) TAPE ALL SEAMS

NOTE:
 EXPOSED PORTION OF PRECAST PILE MUST BE FREE OF VOIDS AND HAVE A MINIMUM WOOD FLOAT FINISH

G:\My Drive\Epro Master Folder\Drafting\Details\Underslab\Pretak\51.121.1 UNDERSLAB PENETRATION - PRECAST PILE.dwg [Detail] April 12, 2021 - 1:19pm

UNDERSLAB PENETRATION - PRECAST PILE

	SYSTEM NAME	DRAWING NUMBER	
	PRETAK	51.121.1	
	DRAFTER	DATE	
	RJT	4/06/2021	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1