



NOTES:

- 1) PRETAK MEMBRANE BOOT MUST BE FIT SNUG AROUND CONDUIT/PIPE WITHOUT FOLDING OR FALLING DOWN. PRETAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PIPE, TIGHTEN HOSE CLAMP AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE
- 2) SPACE PENETRATIONS A MINIMUM OF 6" FROM SLAB EDGE, CORNERS, WALLS, OR OTHER PENETRATIONS.

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Pretak\51.320.1 BLINDSIDE VERTICAL PENETRATION - SOE SHORING.dwg [Detail] April 12, 2021 - 9:20am

BLINDSIDE VERTICAL PENETRATION - SOE WOOD LAGGING

| | | | |
|---|-------------|----------------|---|
|  | SYSTEM NAME | DRAWING NUMBER |  |
| | PRETAK | 51.320.1 | |
| | DRAFTER | DATE | |
| | RJT | 4/06/2021 | |

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1