



NOTES:

- 1) PRETAK MEMBRANE BOOT MUST BE FIT SNUG AROUND BLOCKOUT TUBE WITHOUT FOLDING OR FALLING DOWN. PRETAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND TUBE, TIGHTEN HOSE CLAMP AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE
- 2) SPACE PENETRATIONS A MINIMUM OF 6" FROM SLAB EDGE, CORNERS, WALLS, OR OTHER PENETRATIONS.

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\PreTak\51.328.3 BLINDSIDE VERTICAL PENETRATION - MULTI-CONDUIT/PIPE BUNDLE WITH LIMITED ANNULAR SPACE - SPE_SHORING.dwg [Detail] April 12, 2021 - 9:39am

BLINDSIDE VERTICAL PENETRATION - MULTI-CONDUIT/PIPE BUNDLE WITH LIMITED ANNULAR SPACE - SOE/WOOD SHORING

	SYSTEM NAME	DRAWING NUMBER	
	PRETAK	51.328.3	
	DRAFTER	DATE	
	RJT	4/09/2021	

AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1