


NOTES:

- 1) PRETAK MEMBRANE BOOT MUST BE FIT SNUG AROUND BLOCKOUT TUBE WITHOUT FOLDING OR FALLING DOWN. PRETAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND TUBE, TIGHTEN HOSE CLAMP AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE
- 2) SPACE PENETRATIONS A MINIMUM OF 6" FROM SLAB EDGE, CORNERS, WALLS, OR OTHER PENETRATIONS.

- PRETAK COLLAR WRAP AND TARGET PATCH
w/ PSA TOWARDS CONCRETE
- 1) OVERLAP COLLAR MIN. 4" WITH 6" WIDE PRETAK COLLAR WRAP
 - 2) FOLD PRETAK COLLAR IN HALF LENGTHWISE AND CUT 1" WIDE FLAPS TO CENTER LINE
 - 3) ADHERE COLLAR TIGHTLY TO PRETAPE D ON PENETRATION WITH FLAPS ON SUBSTRATE
 - 4) APPLY PRETAPE D OVER FLAPS
 - 5) SLIDE STAR CUT TARGET PATCH TIGHTLY OVER PENETRATION AND ADHERE TO FLAPS
 - 6) TAPE ALL SEAMS

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Pretak\51.328.4 BLINDSIDE VERTICAL PENETRATION - MULTI-CONDUIT/PIPE BUNDLE WITH LIMITED ANNULAR SPACE - SOE SHOTCRETE.dwg [Detail] April 12, 2021 - 9:40am

BLINDSIDE VERTICAL PENETRATION - MULTI-CONDUIT/PIPE BUNDLE WITH LIMITED ANNULAR SPACE - SOE/SHOTCRETE SHORING

	SYSTEM NAME	DRAWING NUMBER	<h1>PRETAK</h1>
	PRETAK	51.328.4	
	DRAFTER	DATE	
	RJT	4/06/2021	

AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1