



APPLICATION NOTES:

- 1) ENSURE PRETAK PSA IS FACING TOWARDS CONCRETE POUR
- 2) DO NOT TAPE FOLD ONTO EITHER VERTICAL SURFACE.
- 3) SEAM WITH PRETAPE AND PRETAPE D

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Pretak\51.381.3 INSIDE CORNER.dwg [Detail] June 01, 2020 - 10:29am

INSIDE CORNER

|   |             |                |   |
|---|-------------|----------------|---|
|  | SYSTEM NAME | DRAWING NUMBER |  |
|   | PRETAK      | 51.381.3       |   |
|   | DRAFTER     | DATE           |   |
|   | RJT         | 05/26/2020     |   |

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1