


NOTES:

- 1) PRETAK MEMBRANE BOOT MUST BE FIT SNUG AROUND CONDUIT/PIPE WITHOUT FOLDING OF FALLING DOWN. PRETAPE MUST BE USED TO COMPLETELY SEAL BETWEEN BOOT AND PILE, TIGHTEN HOSE CLAMP AS TIGHT AS POSSIBLE WITHOUT DAMAGING THE MEMBRANE
- 2) SPACE PENETRATIONS A MINIMUM OF 6" FROM SLAB EDGE, CORNERS, WALLS, OR OTHER PENETRATIONS.

G:\My Drive\epro Master Folder\Drafting\Details\Shoring\Pretak-HW\52.320.1 VERTICAL PIPE PENETRATION - FIELD MANUFACTURED PIPE COLLAR.dwg [Detail] November 20, 2020 - 2:40pm

VERTICAL PIPE PENETRATION - FIELD MANUFACTURED PIPE COLLAR			
	SYSTEM NAME	DRAWING NUMBER	PRETAK HW
	PRETAK HW	52.320.1	
	DRAFTER	DATE	
	RJT	11/11/2020	
AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.		NTS	PAGE <u> 1 </u> OF <u> 1 </u>