



APPLICATION NOTES:

- 1) ENSURE PRETAK PSA IS FACING TOWARDS CONCRETE POUR
- 2) DO NOT TAPE FOLD ONTO EITHER VERTICAL SURFACE.
- 3) SEAM WITH WEDGE WELD AND EXTRUSION WELD AND TAPE WITH PRETAPE

G:\My Drive\Epro Master Folder\Drafting\Details\Shoring\Pretak-HW\52.381.3 INSIDE CORNER.dwg [Detail] November 20, 2020 - 2:41pm

INSIDE CORNER

	SYSTEM NAME	DRAWING NUMBER	<h1>PRETAK HW</h1>
	PRETAK HW	52.381.3	
	DRAFTER	DATE	
	RJT	11/11/2020	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1