



BENTOTAK  
 (1 1/2" CONCRETE COVERAGE)  
 OR E.STOP GU  
 (3" CONCRETE COVERAGE)

- NOTES:
1. DO NOT APPLY PRIMETAK PRIMER UNDER PM SEALANT
  2. ALLOW PM DETAIL SEALANT TO CURE FOR 2 HOURS BEFORE PRIMETAK APPLICATION
  3. ALL PIPES, CONDUITS, AND SLEEVES SHALL BE FREE OF DIRT, CONCRETE SPLATTER, PAINT, OIL, AND RUST.

G:\My Drive\Epro Master Folder\Drafting\Details\Walls\Primetak\55.220.2 WALL PENETRATION - NON-HYDROSTATIC - INSULATED.dwg [Detail] April 27, 2021 - 8:24am

**WALL PENETRATION - NON-HYDROSTATIC - INSULATED**

	SYSTEM NAME	DRAWING NUMBER	
	PRIMETAK	55.220.2	
	DRAFTER	DATE	
	RJT	2/23/2021	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.