



NOTE:

1. DO NOT APPLY PRIMETAK PRIMER UNDER PM SEALANT
2. ALLOW PM DETAIL SEALANT TO CURE FOR 2 HOURS BEFORE PRIMETAK APPLICATION

G:\My Drive\Epro Master Folder\Drafting\Details\Decks\Primetak\55.425.1 DECK PENETRATION - NON-HYDROSTATIC - SPLIT SLAB WITH 2-STAGE DRAIN.dwg [Detail] April 27, 2021 - 9:10am

DECK PENETRATION - NON-HYDROSTATIC - SPLIT SLAB WITH 2-STAGE DRAIN

	SYSTEM NAME	DRAWING NUMBER	
	PRIMETAK	55.425.1	
	DRAFTER	DATE	
	RJT	3/16/2021	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1